

# HAL-NET kanalliste

Grundpakken		
#	Kanal	Frekvens
1	DR1	346000
2	DR2	346000
3	TV2 (Lorry)	370000
4	TV Syd+	314000
6	TV2 Charlie	362000
9	HAL-Info	378000
30	DK4	410000
31	TV2/Syd	346000
35	Syd	314000
61	SVT1	354000
62	SVT2	362000
78	Sport Live	386000
85	Folketinget	314000
90	DR Ramasjang	346000
100	Das Erste	378000
101	ZDF	410000
105	Deutches Musik Fernsheen	370000
111	ZDF Info	386000
112	Phoenix	354000
113	3sat	370000
113	3sat HD	386000
140	NDR	314000
141	MDR	410000
210	DR1 Syn	346000
212	DR Syn	346000

Mellempakken		
#	Kanal	Frekvens
5	TV2 Zulu	482000
7	TV2 Fri	570000
10	TV3	554000
11	TV3+	562000
20	Kanal4	554000
21	Kanal5	490000
50	Discovery Science	482000
53	BBC Brit	482000
54	BBC Earth	490000
73	TV2 Sport	482000
74	TV2 Sport X	490000
80	TV2 News	570000
81	BBC World	482000

Fuldpakken		
#	Kanal	Frekvens
13	TV3 Max	626000
22	6'eren	634000
70	TV3 Sport	626000
72	V Sport Golf	642000
75	Eurosport 1	634000
76	Eurosport 2	626000

## Kanalsøgning

Frekvens: **346000**  
 Symbol Rate: **6900**  
 QAM: **64**  
 Netværks ID: **1**

Programplads 400 og opefter er radiokanaler.

Firtvalg kanaler		
#	Kanal	Frekvens
200	#TV2 News	170000
201	#TV2 Zulu	170000
202	#TV2 Fri	170000
203	#TV2 Sport	170000
204	#TV2 Sport X	178000

FM Radio		
#	Kanal	Frekvens
509	The Voice	89,2
510	VLR	90
507	DR P4 Trekanten	91,2
500	Classic FM	92
501	Magic UK	93
511	Radio Vinyl	93,5
511	DR P8 Jazz	94,5
502	DR P5 Trekanten	96
503	NDR2	97
505	DR P1	97,5
504	Radio4	98,25
506	DR P3	99,4
508	Nova FM	100,4

Radio kanaler		
#	Kanal	Frekvens
401	DR P1	370000
402	DR P2	370000
403	DR P3	370000
404	DR P4 Trekanten	314000
405	DR P5 Trekanten	314000
406	Magic UK	314000
407	Radio Soft	314000
408	Radio Vinyl	314000
409	DR P8 Jazz	314000
410	NDR Welle Nord	362000
411	NDR2	362000
412	NDR Kultur	362000
420	MDR Klassik	362000
421	MDR Kultur	362000
430	Radio Paloma	370000
431	Slager Radio	370000